




PortaPivot 6530 XL


Grid profile placement



STEALTHPIVOT
By PortaPivot


Patented technology

Delivered parts & recommended tools




Watch our instruction videos on www.portapivot.com

Step 1: design your grid pattern




BOTTOM

Step 2: calculate grid profile lengths




BOTTOM


Step 3: remove adhesive tape around cut line




Step 4: cut grid profiles




Step 5: calculate guide lengths




Step 6: cut guides (2 of each length)




Step 7: degrease panel (preferably with isopropyl alcohol)







Make sure the starting profile is 100% straight! If not, use a rubber hammer to straighten profile.




Place the correct length guide in the bottom left corner.




Use masking tape to keep the guide in place.




Place a second length guide




Take the first grid profile (603 mm)



A small portion of tape should have been removed before the grid profile was cut. This will facilitate positioning.





Remove the backing strip.





Use the length guides to position the grid profile onto the glass.

Make sure the grid profile is perfectly placed against the door frame and glass rubber.



Press down firmly.







Repeat the same steps for the second grid profile.

Place length guides

Place profile




Press down firmly




Repeat the same steps for the first vertical grid profile.

Place length guides


Place profile



Press down firmly



Repeat steps for all remaining grid profiles, using the correct length guides and grid profiles (according to your design).



Flip over the door leaf and repeat all steps for the counterside.

For perfect alignment, start assembly in the same corner as the first side.

For further instructions on how to install
the fully assembled door in your doorway,
please refer to the DOOR INSTALLATION MANUAL